

## The Capsule Filler Machine

### To fill “0” size capsules

Item Catalog Number: 00613

This quality machine from Pure Planet Products allows the user to fill 24 “0” size capsules at a time with as much powder as will fit in the longer “half.” The empty capsules must first be separated and loaded into the base (long half) and cover (short half) of the machine.

### Dosage and Use

- Put large part of The Capsule Machine (the base) on enclosed stand, and then put on flat bowl or plate.
- Separate capsule. Push longer part, open end up, into base, and shorter part into the cover.
- Pour approximately one tablespoon of powdered material into base and sweep enclosed card over holes, filling them. If desired, use enclosed tamping tool to compact powder, and then fill base again.
- Place cover on base, and remove The Capsule Machine from stand. Put The Capsule Machine on flat surface and press down evenly until bottomed out. Release pressure.
- Remove cover. Filled capsules should be in the cover. Depress top cover gently on both sides to eject filled capsules.

All Contents Copyright © 1995-2009 Life Extension Foundation All rights reserved.

**LifeExtension®**

These statements have not been evaluated by the FDA. These products are not intended to diagnose, treat, cure or prevent any disease. The information provided on this site is for informational purposes only and is not intended as a substitute for advice from your physician or other health care professional or any information contained on or in any product label or packaging. You should not use the information on this site for diagnosis or treatment of any health problem or for prescription of any medication or other treatment. You should consult with a healthcare professional before starting any diet, exercise or supplementation program, before taking any medication, or if you have or suspect you might have a health problem. You should not stop taking any medication without first consulting your physician.